



# MASSARELLI'S®

MAKERS OF FINE STONE GARDEN ACCENTS

## SET UP INSTRUCTIONS

### 3714 - 57" GRANDESSA ARCH WALL FOUNTAIN

Open the bag containing the pump kit **P29022**. In the kit you will find:

- |   |                                       |
|---|---------------------------------------|
| 1 - KING-40400 (400 gallon per hour pump) | 1 - 14" long piece of 1" clear tubing |
| 1 - 2" long piece of 3/4" clear tubing    | 2 - hose clamp                        |

1. Place the fountain pool section on a firm and level area where the fountain will remain. Level in all directions.
2. Find the pump and the 3/4" clear tubing 2" long. Slip the piece of 3/4" clear tubing 2" long onto the outlet side of the pump. Place the pump in the rear center of the fountain pool and place the electrical cord in the groove and out over the back wall.
3. Find the fountain wall piece, the piece of 1" clear tubing 14" long and one hose clamp. Below the large shell there is a pipe. Connect one end of the 1" clear tubing to the pipe with a hose clamp
4. **Place two strong 2X4 boards (about 48" long and space about 30" apart) on the top surface of the front wall and across on the back wall of fountain pool section. Carefully, place the fountain wall piece onto the boards. Carefully, walk the fountain wall piece one side at a time on the boards until the fountain wall piece is positioned over the back wall of the fountain pool section. Lift one side of the fountain wall piece slightly and remove one board. Rest that side of the fountain wall piece on the rear wall. Lift the opposite side the fountain wall piece slightly and remove the second board. Rest that side of the fountain wall piece on the rear wall.**
5. **Carefully**, tilt the fountain wall piece slightly towards the rear of the fountain. **Carefully** position the pump cover centered under the large bowl and up against the rear wall of the fountain pool. **Carefully** rest the fountain wall piece on the pump cover.
6. *Attach the opposite end of the 1" clear tubing to the outlet of the pump with the second hose clamp. If necessary trim the 1" clear tubing to length making sure the pump is seated on the bottom of the fountain pool. Find the pump house plug and position it in the hole in the pump cover.*
7. Find the drain plugs and insert snugly into the drain inserts located in the pool section and the two shells of the fountain. Remove any tape and or dirt from the drain insert before you insert the drain plug. Fill the pool and the two shells with tap water and plug the pump into a 110VAC GFCI protected outlet. To adjust the water flow use the dial type flow control located on the front of the pump until the desired result is achieved.

3714sup      6/6/11