



MASSARELLI'S®

MAKERS OF FINE STONE GARDEN ACCENTS

SET UP INSTRUCTIONS

3780 - THREE TIER BOCA ROUND FOUNTAIN

Open bag containing the pump kit **P22514**. In the kit you will find:

1 – 40225 (225 gallon per hour pump)	1 - rubber stopper	1 – hose clamp
1 - 48" long piece of 3/4" clear tubing	1 – tube of silicone	

1. Place the pedestal on a firm and level surface where fountain will remain and level in all directions. Place the largest shell on the pedestal.
2. Find the pump, the piece of 3/4" clear tubing 48" long and the rubber stopper. Place pump in the pump house in the center of the shell and run the plug end of the electrical cord down the PVC insert in the pump house and down into the pedestal base. Retrieve cord from inside the pedestal and place in the groove in the bottom of the pedestal. Slip the rubber stopper onto the power cord about 15" from the pump with the smaller end facing away from the pump. Insert the rubber stopper snugly into the PVC insert. Attach the piece of 3/4" clear tubing 48" long onto the outlet side of the pump with the hose clamp. Make sure the pump is seated on the bottom of the pump house.
3. Position the largest shell on pedestal and level in all directions.
4. Find the spacer. Run the 3/4" clear tubing through the center hole in the spacer. Position the spacer on top of pumphouse in center of large shell and level in all directions.
5. Find the second shell and run the 3/4" clear tubing up thru the hole in the center housing of the shell. Position the shell on top of the spacer and level in all directions.
6. Find the third shell and run the 3/4" clear tubing up thru the hole in the center housing of the shell. Position the shell on top of the second shell and level in all directions.
7. Make sure the pump is seated on the bottom of the pump house.
Cut the 3/4" clear tubing 4" above the top surface of the center housing on the third shell.
Find the finial and insert the 3/4" clear tubing into the PVC pipe in the bottom of the finial and slide the finial down onto the center housing of the third shell. Position the finial on the fountain.
8. Find the drain plugs and insert them snugly into the drain inserts located in the two larger shells of the fountain. Remove any tape and or dirt from the drain insert before you insert the drain plug. Find the pump house plug and position in the opening in the pump house.
9. Fill shells with tap water and plug pump into a 110VAC GFCI protected outlet. Adjust the water flow to the finial using the dial type flow control located on the front of the pump until the desired result is achieved.

3780sup 2/28/14