



# MASSARELLI'S®

MAKERS OF FINE STONE GARDEN ACCENTS

## SET UP INSTRUCTIONS

### 3594 62" OPAL TWO TIER FOUNTAIN WITH POOL

Open bag containing the pump kit **P40004**. In the kit you will find:

- 1 - 40400 (400 gallon per hour pump)    1 - rubber stopper
- 1 - 60" long piece of 3/4" clear tubing    1 - 12" long piece of putty tape

1. Place pool on a firm level surface where fountain will remain. Place a brick under one side of pool to help you retrieve the pump power cord.
2. Find the pump, the rubber stopper and the piece of 3/4" clear tubing 60" long. Place the pump into the pump house located in center of the pool. Run the plug end of the electrical cord down the PVC pipe located in the pump house. Retrieve cord from under pool and place in groove in bottom of pool. Slip the rubber stopper onto the power cord about 12" from the pump with the smaller end facing away from the pump. Insert the rubber stopper snugly into the PVC pipe. Make sure the pump is seated on the bottom of the pump house. Adjust position of the rubber stopper on the power cord if necessary. Remove brick from under pool and level.  
Attach the piece of 3/4" clear tubing 60" long to the outlet side of the pump.
3. To level pool, place the level on the top rim of the pump house in the center of the pool. Level in (2) two directions left to right and front to back. **Shim if needed.**
4. Place a couple of pieces of padding on the pump house in the center of the pool. Place the pedestal on the pump house. Have one person tilt and hold the pedestal while you run the 3/4" clear tubing 60" long up thru the bottom of the pedestal. Remove the padding. Position the pedestal on the pump house and level. To level the pedestal, place the level on top of pedestal. Level as stated in step #3.
5. Find the larger shell. Run the 3/4" clear tubing up thru the PVC insert in the center housing of the shell and place the shell on the pedestal. Make sure that the 3/4" clear tubing is free of kinks. Position the shell on pedestal and level. To level shell, place level on top rim of the center housing in the center of shell. Level as stated in step #3.
6. Find the spacer. Run the piece of 3/4" clear tubing that is attached to the pump, up thru the center hole and place spacer on the center housing of the larger shell and level. To level spacer, place level on top of the spacer. Level as stated in step #3.
7. Find the second shell. Run the 3/4" clear tubing up thru the PVC insert in the center housing of the shell. Position this shell on top of the spacer and level. To level shell, place level on center housing in center of shell. Level as stated in step #3. Trim the 3/4" clear tubing 11" above the top surface of the center housing.
8. Find the piece of putty tape 12" long. Located in the center housing of the second shell you will see the PVC insert with the 3/4" clear tubing in the center. You are going to apply the putty tape around the 3/4" clear tubing and into the PVC insert. **Apply as much putty tape around the 3/4" clear tubing and down into the PVC pipe as you can, keeping the 3/4" clear tubing in the center of the PVC pipe.**
9. Find the finial. On the bottom of the finial you will see a PVC pipe. Clean any excess concrete or tape from both ends and inside of this PVC pipe. Slip the finial onto the 3/4" clear tubing and position the finial on top of fountain.
10. Find the three drain plugs and insert snugly into the drain inserts located in the pool and the two shells. Remove any tape and or dirt from the drain inserts before you insert the drain plugs. Fill shells with water and plug pump into a 110VAC GFCI protected outlet. Adjust water flow to the finial using the dial type flow control located on the front of the pump until the desired result is achieved.

**3594sup** 9/9/09