

SET UP INSTRUCTIONS

3764 – TRANQUIL COLUMN FOUNTAIN

Open the bag containing the pump kit **P22512**. In the kit you will find:

1 - 40225 (225 gallon per hour pump)	1 – 3/4" female adaptor	1 – rubber stopper
1 – 3/4" kink free tubing 10" long	1 – 3/4" barb adaptor	1 – tube of silicone

1. Find the fountain base, the pump and the rubber stopper. Slip the rubber stopper onto the power cord about 10" from the body of the pump with the smaller end facing away from the pump.
2. Run the plug end on power cord of the pump down the PVC insert located in the center of the fountain base and out the bottom of the fountain base. Retrieve the power cord from under the fountain base and place in the groove in the bottom of the fountain base.
3. Find the tube of silicone. **For a watertight seal apply silicone around the top inside edge of the PVC insert and around the outside edge of the rubber stopper. Insert the rubber stopper snugly into the PVC insert. Apply more silicone around the top of the rubber stopper and the wire.**
4. Place the fountain base on a firm and level area where the fountain will remain.
5. Find the 3/4" kink free tubing and attach one end to the outlet side of the pump. Find the 3/4" female adaptor and the 3/4" barb adaptor and screw the two pieces together. Attach the barbed end of the 3/4" barb adaptor to the opposite end of the 3/4" kink free tubing.
6. Find the pump house and position it within the scribe lines in the bottom of the fountain base. The square opening in the pump house wall will be facing away from the drain plug.
7. Find the finial. On a padded surface, **CAREFULLY**, lay the finial on its side. In the bottom of the finial there is a PVC pipe. Clean any tape and or dirt from the PVC pipe. Place the finial on the pump house with the tall drip side on the side of the square opening. **CAREFULLY**, connect the slip end of the 3/4" female adapter onto the PVC pipe. Push the adaptor onto the PVC pipe until it bottoms out. Position the finial on the pump house.
8. Reach in the square pump house opening and position the pump with the face of the pump down.
9. Find the pump house plug and position it in the square pump house opening. Find the pipe cap. The pipe cap looks like a cylinder 3.5" long and 3.5" diameter with a fluted end. Place the fluted end of the pipe cap into the top cavity of the finial covering the water outlet.
10. Find the drain plug and insert the snugly into the drain insert located in the fountain base. Remove any tape and or dirt from the drain insert before you insert the drain plug.
11. Fill the fountain bowl with tap water. Plug the pump into a 110VAC GFCI protected outlet. If necessary, adjust the water flow using the dial type flow control located on the front of the pump.