

## SET UP INSTRUCTIONS

PAGE 1 OF 3

3891- FTNETTE - PETAL POINT  
3892 - FTNETTE – DRAGONFLY  
3893 - FTNETTE – BUTTERFLY  
3987 - FTNETTE - GARDEN GLOW  
3992 - FTNETTE - SAILBOAT  
3993 - FTNETTE - PETITE BIRD  
3916 - FTNETTE – THREE DOVES  
3923 – FTNETTE - ROSE

3999 - FTNETTE – GLOBE  
3901 - FTNETTE - FROG  
3903 - FTNETTE - TURTLE  
3904 - FTNETTE - FAIRY  
3907 - FTNETTE – SITTING ANGEL  
3909 - FTNETTE – SINGING BIRDS  
3917 - FTNETTE – RIBBON OF TRIBUTE

Open the bag containing the pump kit **P13014**. In the kit you will find:

1 - 40130 (130 gallon per hour pump)	1 – 2-hole rubber stopper	1 - hose clamp
1 – 8" long piece of 1/2" kink free tubing	1 - LED light kit (white)	

1. Place the fountain pedestal on a firm and level area where the fountain will remain. On a padded surface place the fountain bowl along side the pedestal. Inside the fountain bowl there is a PVC pipe. Find the pump and the LED light kit. Run the plug end of both power cords down the PVC pipe and out the bottom of the bowl leaving about 12" of wire inside the bowl.

2. Run both power cords down the hole located in the pedestal and out the bottom. Retrieve both power cords from under pedestal and place both power cords in the groove in the bottom of the pedestal. Carefully place the fountain bowl on the pedestal. Pull the remainder of both power cords out from the bottom of the pedestal. Position the bowl on the pedestal.

3. Find the 2-hole rubber stopper. Slip the 2-hole rubber stopper onto the power cord of the pump and the power cord of the LED light. Position the 2-hole rubber stopper about 12" from the body of the pump and about 12" from the LED light. Insert the 2-hole rubber stopper snugly into the PVC pipe.

4. Find the 1/2" kink free tubing 8" long and the hose clamp. Attach the 1/2" kink free tubing to the outlet side of the pump with the hose clamp. Insert the LED light head into the opposite end of the 1/2" kink free tubing. Place the pump in the center of the bowl with the tubing assembly facing up.

**Add 6" of water in the fountain bowl.**

5. Find the pump cover and place it onto the bowl **CAREFULLY** guiding the LED light up through the hole in the center of the pump cover. Position the pump cover centered inside of the bowl. The LED light head will extend beyond the pump cover. **Carefully** push the LED light head down into the hole in the pump cover lining up the housing around the LED lights with the top edge of the pump cover. If necessary, trim the length of the 1/2" kink free tubing so that the housing around the LED lights will be even with the top edge of the pump cover. If so, remove the pump cover and set aside. Remove the LED light head from the 1/2" kink free tubing and place inside the fountainette bowl. Trim the 1/2" kink free tubing to the proper length. Reassemble the LED light head and the pump cover.

6. Connect the power cord on the LED light to the transformer. Plug both the pump and the LED light transformer into a 110VAC GFCI protected outlet.

3891sup

7/12/13

## SET UP INSTRUCTIONS

### 3908- FOUNTAINETTE – CLOVER LEAF

### 3911 - FOUNTAINETTE – FLOWER

### 3926 – 16” ROSE FLOWER FOUNTAIN

Open the bag containing the pump kit **P13014**. In the kit you will find:

1 - 40130 (130 gallon per hour pump)	1 – 2-hole rubber stopper	1 - hose clamp
1 – 8” long piece of 1/2" kink free tubing	1 - LED light kit (white)	

1. Place the fountain bowl on a firm and level area where the fountain will remain. Inside the fountain bowl there is a PVC pipe. Find the pump and the LED light kit. Run the plug end of both power cords down the PVC pipe and out the bottom of the bowl leaving about 12” of wire inside the bowl. Retrieve both power cords from under the bowl and place both power cords in the groove in the bottom of the bowl.

3. Find the 2-hole rubber stopper. Slip the 2-hole rubber stopper onto the power cord of the pump and the power cord of the LED light. Position the 2-hole rubber stopper about 12” from the body of the pump and about 12” from the LED light. Insert the 2-hole rubber stopper snugly into the PVC pipe.

4. Find the 1/2" kink free tubing 8" long and the hose clamp. Attach the 1/2" kink free tubing to the outlet side of the pump with the hose clamp. Insert the LED light head into the opposite end of the 1/2" kink free tubing. Place the pump in the center of the bowl with the tubing assembly facing up.

**Add 5” of water in the fountain bowl.**

5. Find the pump cover and place it onto the bowl **CAREFULLY** guiding the LED light up through the hole in the center of the pump cover. Position the pump cover centered inside of the bowl. The LED light head will extend beyond the pump cover. **Carefully** push the LED light head down into the hole in the pump cover lining up the housing around the LED lights with the top edge of the pump cover. If necessary, trim the length of the 1/2" kink free tubing so that the housing around the LED lights will be even with the top edge of the pump cover. If so, remove the pump cover and set aside. Remove the LED light head from the 1/2" kink free tubing and place inside the fountainette bowl. Trim the 1/2" kink free tubing to the proper length. Reassemble the LED light head and the pump cover.

6. Connect the power cord on the LED light to the transformer. Plug both the pump and the LED light transformer into a 110VAC GFCI protected outlet.

## SET UP INSTRUCTIONS

PAGE 3 OF 3

- 3708 CHELSEA TWO TIER ROUND FOUNTAIN
- 3711 CHELSEA TWO TIER FLUTED FOUNTAIN
- 3728 CHELSEA TWO TIER HEXAGON FOUNTAIN
- 3729 CHELSEA TWO TIER SQUARE FOUNTAIN

Open bag containing the pump kit **P13014**. In the kit you will find:

- |  |                           |                           |
|--|---------------------------|---------------------------|
| 1 - 40130 (130 gallon per hour pump)       | 1 – 2-hole rubber stopper | 1 – LED light kit (white) |
| 1 – 8" long piece of 1/2" kink free tubing | 1 - hose clamp            |                           |

1. Place the pedestal on a firm and level surface where fountain will remain. Place the shell on the pedestal.
2. Find the pump, the LED light kit and the 2-hole rubber stopper. Slip the 2-hole rubber stopper onto the power cord of the pump and the power cord of the LED light kit. Position the 2-hole rubber stopper about 6" from the body of the pump. Position the 2-hole rubber stopper about 8" from the LED light.
4. Place pump and the LED light in the shell and run the plug end of both power cords down the hole located in the center of the pump house and down through the pedestal. Retrieve both cords from under pedestal and place in the groove in the bottom of pedestal. Pull the remainder of both power cords out from the bottom of the pedestal. Insert the 2-hole rubber stopper snugly into the hole. Position the shell on the pedestal and level. To level shell, place level on the top rim of the shell. Level in (2) Two directions left to right and front to back. **Shim as needed.**
5. Find the piece of 1/2" kink free tubing 8" long and hose clamp. Attach the 1/2" kink free tubing to the outlet side of the pump with the hose clamp. Insert the LED light head into the opposite end of the 1/2" kink free tubing. Place the pump in the pumphouse with the tubing assembly facing up
6. Find the finial. In the center of the finial there is a PVC pipe. Remove any excess concrete or tape from both ends of this PVC pipe. Place the finial onto the shell **CAREFULLY** guiding the LED light head up through the center hole. Position the finial in the center of shell.
7. Fill the shell with water and plug pump into a 110VAC GFCI protected outlet. Adjust the water flow to the finial using the built in flow control dial on the front of the pump.

3891sup 7/12/13